


AF10

Exploded parts diagram







Part Number	Number	Description	Qty
B3-AF1011	1	Water Pan	1
B3-AF1012	2	Tap	1
***	3	Base Plate	1
***	4	Rubber Feet	4
***	5	Cable Plate	1
***	6	Back Panel	1
***	7	Chamber	1
***	8	Temp. Sensor	1
B3-AF1019	9	Heating Element	1
***	10	Inflowing Bellows	1
***	11	Back Damper	1
***	12	PCB Support Panel	1
***	13	Cable Clamp	1
B3-AF10113	14	Power Cord	1
B3-AF10115	15 & 16	Temperature Display and Ops Board	1
***	17	Top Cover	1
***	18	Outer Case	1
***	19	Chamber Mounting Plate	1
***	20	Chamber Cover Plate	1
***	21	Silicone Seal	1
B3-AF10122	22	Solenoid Valve	1
B3-AF10123	23	High Level Water Sensor	1
B3-AF10123	24	Low Level Water Sensor	1
B3-AF1018	25	Temperature Sensor	1
B3-AF1026	26	PC Board	2
***	27	Power Switch	1
***	28	Binding	1

*** Please contact Spares for assistance ***